


Thread on both clamps and Thread each clamp all the way down the thread going in a back and forth motion on any areas that give resistance to make sure it threads smoothly once fully assembled. Try to make sure they are both the same distance from the middle to ensure your clamped workpiece is always centered.



Attach both of the thread ends, the ends can become loose very easily, so its recommended to apply a little glue to make sure it stays that is not necessary. If you glue, it will become impossible to get off later without damaging the thread.



Place assembled thread on the bottom

