

PrintCity

3D · Innovate · Educate · Collaborate

Armie

Pull Door

Installation Instructions

1. Secure the door in place.



2. Push Armie against the door at 90 degrees.



3. Place Armie against the pull handle towards the top.



4. Thread cable ties through the holes aligned to the handle.



5. Loop the cable tie over the pull handle and Armie.



6. Tighten the cable tie around the handle. Add an additional tie around the top of the handle to prevent Armie sliding.



7. Use your arm to open the drawer using Armie.

