

Pull Door Installation Instructions

2. Pull *Armo* against the door at 90 degrees.



3. Place *Armo* against the pull handle towards the top.



4. Thread cable ties through the holes aligned to the handle.



5. Loop the cable ties over the pull handle and *Armo*.



6. Tighten the cable ties around the handle. Add an additional tie around the top of the handle to prevent *Armo* sliding.



7. Use your arm to open the drawer using *Armo*.

